



Vehicles shown have been altered or upfitted with equipment supplied by independent suppliers. See the Owner Manual for information on alterations and warranties.

Carrying everything from livestock to lumber and scrap metal, platform/stake applications are among the most versatile of work trucks. Properly spec'd, they can meet the diverse needs of many different types of customers.

See Powertrain Combinations chart for applicable engines, transmissions and 2WD/4WD availability.

Model	Cab or Equipment	WB/CA (inches)	Drive Axle(s)	Body Length (feet)						Maximum GVWR (pounds) ¹	Maximum Body and Payload (pounds) ²	
				6	7	8	9	10	12			
Colorado	Chassis Cab	126/48.9	2WD/4WD	■	■	■				5500	2179 (2WD)/1982 (4WD)	
Silverado/Sierra 2500HD (with ZW9 Pickup Box Delete)	Regular Cab	133.7/56.0	2WD			■				10000	4195	
			4WD			■				9900	4054	
	Extended Cab	158.2/55.6	2WD			■				10000	3889	
			4WD			■				10000	3602	
	Crew Cab	167.7/55.6	2WD			■				10000	3770	
			4WD			■				10000	3816	
Silverado/Sierra 3500HD (with ZW9 Pickup Box Delete)	Regular Cab	133.7/56.0	2WD			■				11100 SRW 13400 DRW	5160 SRW 7815 DRW	
			4WD			■				11400 SRW 13400 DRW	5135 SRW 7490 DRW	
	Extended Cab	158.2/55.6	2WD			■				11200 SRW 13000 DRW	4965 SRW 6917 DRW	
			4WD			■				11600 SRW 13000 DRW	4983 SRW 6593 DRW	
	Crew Cab	167.7/55.6	2WD			■				11400 SRW 13000 DRW	4826 SRW 6811 DRW	
			4WD			■				11600 SRW 13000 DRW	4765 SRW 6450 DRW	
	Silverado/Sierra 3500HD Chassis Cab	Regular Cab SWB	137.5/59.8	2WD			■	■			13200	7499
				4WD			■	■			13200	7066
Regular Cab LWB		162.0/84.3	2WD				■	■	■	13200	7294	
			4WD				■	■	■	13200	6954	
Crew Cab		171.5/59.4	2WD			■	■			13200	6791	
			4WD			■	■			13200	6443	

1. When properly equipped; includes weight of vehicle, passengers, cargo and equipment.

2. When properly equipped; maximum payload capacity includes weight of driver, passengers, optional equipment and cargo.