

2019 SNOW PLOW/SPREADER BODY APPLICATION CHART										
Vehicle	Cab Configuration	WB/CA (inches)	Body Length (feet)	Drive Type	DRW/SRW	Plow Width (feet)	Spreader/Hopper Length (feet)	Maximum Front GAWR ¹ (pounds)	Maximum GVWR ² (pounds)	Maximum Body & Payload ³ (pounds)
Chevrolet Silverado 1500 GMC Sierra 1500	Regular Cab	139.6/55.2	8	4WD	SRW	7.5	7/8	3800	6900	2070
	Double Cab	147.5/42.1	7	4WD	SRW	7.5		3800	7300	2180
	Crew Cab	147.4/32.6 157.0/42.1	6,7	4WD	SRW	7.5		3800	7300	2170
Chevrolet Silverado 2500HD GMC Sierra 2500HD	Regular Cab	133.6/55.16	8	4WD	SRW	7.5/8	7/8	4400	9500	3410
	Double Cab	144.2/41.26 158.1/55.24	7,8	4WD	SRW	7.5/8	7/8	4800	9500	3276
	Crew Cab	153.7/41.26 167.7/55.24	7,8	4WD	SRW	7.5/8	7/8	5600	10,000	3233
Chevrolet Silverado 3500HD GMC Sierra 3500HD	Crew Cab	153.7/41.26 167.7/55.24	7,8	4WD	SRW	7.5/8	7/8	5600	11,500	4058
	Crew Cab	167.7/ 55.24	8	4WD	DRW	8/9	7/8	5600	13,025	6112
Chevrolet Silverado 3500HD Chassis Cab GMC Sierra 3500HD Chassis Cab	Regular Cab	137.5/59.06 162/83.58	8,10	4WD	DRW	8/9	8/10	5600	13,200	7287
	Crew Cab	171.5/59.06	8	4WD	DRW	8/9	7/8	5600	13,200	6580
Chevrolet Silverado 4500HD Chassis Cab	Regular Cab	141/60 165/84 189/108 201/120 219/138 231/150 243/162	8,10,12,14, 15,16,17	2WD/ 4WD	DRW	8/9		7000	16,500	TBD
	Crew Cab	175/60 199/84 235/120	8,10,14	2WD/ 4WD	DRW	8/9		7000	16,500	TBD
Chevrolet Silverado 5500HD Chassis Cab	Regular Cab	141/60 165/84 189/108 201/120 219/138 231/150 243/162	8,10,12,14, 15,16,17	2WD/ 4WD	DRW	8/9		8000	19,500	TBD
	Crew Cab	175/60 199/84 235/120	8,10,14	2WD/ 4WD	DRW	8/9		8000	19,500	TBD
Chevrolet Silverado 6500HD Chassis Cab	Regular Cab	141/60 165/84 189/108 201/120 219/138 231/150 243/162	8,10,12,14, 15,16,17	2WD/ 4WD	DRW	8/9		8000	23,500	TBD
	Crew Cab	175/60 199/84 235/120	8,10,14	2WD/ 4WD	DRW	8/9		8000	23,500	TBD

1. Gross Axle Weight Rating (GAWR). When properly equipped; includes weight of vehicle, passengers, cargo and equipment.
2. Gross Vehicle Weight Rating (GVWR). When properly equipped; includes weight of vehicle, passengers, cargo and equipment
3. Before you buy a vehicle or use it to haul people or cargo, carefully review the Vehicle Loading section of the Owner's Manual and check the carrying capacity of your specific vehicle on the label on the inside of the driver door jamb.